

Pharmacy Plus Series

Freestanding Undercounter/Countertop Refrigerators

The Pharmacy Plus Series Freestanding Undercounter/Countertop Refrigerators feature a microprocessor temperature controller and display, which allows for precise temperature control, verification and recovery versus mechanical style thermostats. Refrigerators feature an interior fan driven, forced-draft air circulation system provides excellent temperature uniformity and recovery after door openings.



PH-DAI-HC-UCFS-0504G

PH-DAI-HC-UCFS-0204



- Digital temperature display
- Audible and visual temperature alarms
- Resettable Min/Max
- °C/°F switchable



Environmentally friendly, natural hydrocarbon (HC) refrigerants that vastly reduce global-warming potential while meeting new EPA/SNAP mandates.

FEATURING

- Microprocessor temperature controller
- Adjustable temperature range: 36°F to 46°F (2°C to 8°C)
- Cycle defrost
- Remote alarm contacts
- Back wall evaporator cover
- Forced draft circulation
- Keyed door lock
- Magnetic door gasket for positive seal
- Leveling legs
- LED interior lights (select models)
- Probe access port
- Temperature Monitor Device - complies with the current CDC guidelines, 3 years certification of calibration, "buffered" probe in the product simulated solution, min/max memory, °F/°C switchable, field installable, and visual & audible temperature alarms
- Vaccine storage power cord warning label
- Pharmacy refrigerator/freezer toolkit with temperature logs
- Pyxis®, Omnicell® and AcuDose RX® compatible
- UL/C-UL listed
- Two year parts and labor warranty, plus an additional three year compressor parts warranty
- These models require 4" of clearance around back and sides of the unit for proper ventilation. Improper installation will void the warranty and will lead to temperature maintenance issues, overheating and possible failure

Glass Door Model	Ft ³	Set Point	Defrost	Doors	Shelves	Width"	Depth"	Height"
 PH-DAI-HC-UCFS-0104G*	1	41°F	Cycle	1 Glass	2 Adj.	17 ¼	19 ¼	21 ¼
 PH-DAI-HC-UCFS-0204G	2.5	41°F	Cycle	1 Glass	4 Adj.	17 ¾	19 ½	28 ⅞
 PH-DAI-HC-UCFS-0504G	5.2	41°F	Cycle	1 Glass	3 Adj.	23 ¾	24	32 ⅞
Solid Door Model								
 PH-DAI-HC-UCFS-0104*	1	41°F	Cycle	1 Solid	2 Adj.	17 ¼	19 ¼	21 ¼
 PH-DAI-HC-UCFS-0204	2.5	41°F	Cycle	1 Solid	4 Adj.	17 ¾	19 ½	28 ⅞
 PH-DAI-HC-UCFS-0504	5.2	41°F	Cycle	1 Solid	3 Adj.	23 ¾	24	32 ⅞

Specifications are subject to change
*Left hinge model available